































2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
100-001	Slide Hammer	X		X		 100-001
100-002	Dial Indicator Gauge with Holding Fixture	X		X		
100-010	Remover, O-Ring Seal	X				
100-D002	Dial Indicator Gauge with Holding Fixture		X		X	
100-D009	Rubber Tip Air Nozzle		X		X	 100-D009
100-D112	Set, Slider Hammer Master		X		X	
204-142	Remover/Installer, Lower Arm Bushing Receiver	X				
204-161	Installer, Halfshaft	X		X		
204-164	Gauge, Ride Height "D" Dimension	X		X		
204-172	Remover/Installer, Ball Joint	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
204-180	Remover/Installer, Bushing	X		X		
204-182	Remover, Ball Joint	X		X		
204-185	Remover/Installer, Torsion Bar	X				
204-186	Remover, Front Differential Housing Bushing	X		X		
204-187	Installer, Front Differential Housing Bushing	X		X		
204-188	Aligner, Front Differential Housing Bushing	X				
204-204	Adapter For 204-185 (Spacer)	X				
204-322	Installer, Water Seal Carrier (Drum Brake)	X				
204-325	Installer, Water Seal	X				
204-354	Gauge, Digital Tire Pressure	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
204-355	Remover/Installer, Ball Joint	X				
204-356	Remover/Installer, Radius Arm Axle Bushing	X				
204-358	Remover/Installer, Ball Joint	X		X		
204-362	Remover/Installer, Front Subframe Bushing	X		X		
204-589	ASSEMBLY, Spacer	X		X		
204-590	Replacer, Rear Knuckle Bushing	X				
204-592	Separator, Lower Arm Ball Joint	X		X		
204-594	Forcing Screw	X				
204-608	Remover, Bushing	X		X		
204-616	Remover/Installer, Rear Drive Unit Bushing (70 mm)	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
204-617	Remover/Installer, Rear Drive Unit Bushing (65 mm)	X		X		
204-618	Remover/Installer, Rear Drive Unit Bushing (60 mm)	X		X		
204-816	Tool, Rack Holding	X				
204-D001	Compressor, Coil Spring		X			
204-D081A	Tool, Tire Pressure Monitor (TPMS)					
205-001	Spreader, Differential Carrier	X		X		
205-002	Installer, Drive Pinion Flange	X		X		
205-004	Installer, Drive Pinion Bearing Cone	X				
205-005	Installer, Drive Pinion Bearing Cone	X		X		
205-006	Installer, Drive Pinion Bearing Cup	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-009	Installer, Differential Side Bearing	X				
205-010	Installer, Differential Side Bearing	X		X		
205-012	Holding Fixture, Drive Pinion Flange	X				
205-014	Installer, Drive Pinion Bearing Cup	X				
205-018	Remover, Drive Pinion Flange	X				
205-022	Gauge, Differential Clutch	X		X		
205-024	Installer, Drive Pinion Bearing Cup	X		X		
205-036	Wrench	X				
205-054	Installer, Drive Pinion Bearing Cup	X				
205-055	Remover, Bearing	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-062	Installer, Differential Bearing	X				
205-075	Installer, Wheel Hub Oil Seal	X				
205-086	Remover/Installer, C-Frame and Screw	X		X		
205-090	Plate, Bearing/Oil Seal	X		X		
205-092	Installer, Rear Axle Bearing/Oil Seal	X				
205-098	Drawbar, Rear Axle	X				
205-099	Installer, Axle Bearing	X				
205-100	Installer, Axle Bearing	X				
205-1007	Wrench, Hub Wrench	X				
205-1010	Puller, RDU Coupler Coil	X				









2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-1013	Installer, Rear Axle Pilot Bearing	X				
205-1014	Disc, Gauge	X				
205-1015	Tube, Gauge	X				
205-1016	Installer, Differential Bearing	X				
205-105	Adapter, Aligning	X		X		
205-109	Screw	X		X		
205-110	Block, Gauge	X		X		
205-111	Handle	X		X		
205-115A	Installer, Drive Pinion Oil Seal	X				
205-116	Remover, Differential Bearing	X		X		










2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-117	Plate, Step	X		X		
205-118	Installer, Differential Bearing Cup	X				
205-123	Installer, Axle Shaft Oil Seal	X		X		
205-124	Installer, Axle Shaft Bearing	X		X		
205-125	Disc, Gauge	X				
205-126	Fixture, Drive Pinion Flange Holding	X		X		
205-129	Disc, Gauge	X		X		
205-130	Tube, Gauge	X		X		
205-133	Installer, Drive Pinion Oil Seal	X		X		
205-135	Gauge, Differential Clutch	X		X		




2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-138	Installer, Drive Pinion Bearing Cup	X		X		
205-140	Installer, Drive Pinion Bearing Cup	X		X		
205-142	Installer, Differential Bearing Cone	X		X		
205-147	Installer, Wheel Hub Bearing Cup	X		X		
205-149	Installer, Spindle Bearing	X		X		
205-150	Installer, Spindle Bearing	X		X		
205-153	Adapter for 303-224 (Handle)	X		X		
205-154	Installer, Rear Axle Bearing	X				
205-155	Installer, Rear Axle Oil Seal	X				
205-159	Adapter for 205-S156 Pinion Depth Gauge	X		X		










2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-160	Adapter for 205-S156 Pinion Depth Gauge	X		X		
205-175	Socket, Drive Pinion Nut	X				
205-193	Remover, Axle Bearing	X				
205-194	Installer, Axle Bearing	X				
205-199	Installer, Spindle/Axle Shaft	X		X		
205-206	Installer, Differential Bearing	X				
205-208	Installer, Drive Pinion Oil Seal	X		X		
205-219	Remover, Axle Bearing	X		X		
205-220	Installer, Differential Shim	X		X		
205-224	Remover, Axle Bearing	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-225	Installer, Axle Bearing Cup	X		X		
205-226	Gauge/Aligner, Drive Pinion Depth	X		X		
205-228	Installer, Differential Shim	X		X		
205-229	Protector, Drive Pinion Thread	X		X		
205-231	Installer, Drive Pinion Bearing	X				
205-232	Installer, Drive Pinion Bearing	X				
205-233	Installer, Drive Pinion Flange	X		X		
205-241	Remover, Halfshaft	X		X		
205-247	Gauge, Differential Dummy Bearing	X				
205-253	Remover, Wheel Knuckle	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-256	Installer, Front Wheel Hub Oil Seal	X		X		
205-259	Installer, Axle Oil Seal	X				
205-270	Gauge, Differential Clutch	X		X		
205-275	Remover, Rear Wheel Hub Bearing Cup	X				
205-276	Installer, Front Wheel Hub Oil Seal	X		X		
205-277	Remover, Rear Wheel Hub Bearing Cup	X				
205-278	Installer, Rear Wheel Hub Bearing Cup	X				
205-280	Gauge/Aligner, Drive Pinion Depth	X				
205-281	Gauge/Aligner, Drive Pinion (Handle)	X				
205-282	Socket, Wheel Hub Nut	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-285	Installer, Drive Pinion Flange	X				
205-289	Installer, Wheel Hub Dust Seal	X		X		
205-290	Remover, Halfshaft (Plate)	X		X		
205-304A	Installer, Drive Pinion Oil Seal	X				
205-319	Gauge, Drive Pinion Flange Runout	X		X		
205-320	Plate, Driveshaft Clamp	X		X		
205-323	Gauge, Drive Pinion Runout	X				
205-325	Gauge, Drive Pinion Flange (Pin)	X				
205-335	Spreader, Differential Housing (Plate)	X		X		
205-345	Installer, Front Axle Bearing	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-353	Installer, Front Wheel Spindle Oil Seal	X				
205-356	Adapters, Differential Housing Spreader	X				
205-377	Tube, Drive Pinion Gauge	X		X		
205-378	Rotator, Differential	X		X		
205-381	Installer, Rear Axle Oil Seal	X				
205-382	Installer, Rear Axle Differential Bearing	X				
205-383	Gauge/Aligner, Drive Pinion Depth	X		X		
205-384	Gauge, Differential (Traction Lock)	X		X		
205-385	Gauge, Differential (Traction Lock)	X		X		
205-386	Gauge, Differential (Traction Lock)	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-387	Installer, Rear Axle Bearing Cup	X		X		
205-389	Gauge, Differential (Traction Lock)	X		X		
205-390	Installer, Rear Axle Oil Seal	X				
205-393	Installer, Drive Pinion Flange	X				
205-420	Remover, Wheel Hub Outer Bearing Cup (10 1/2")	X				
205-421	Remover, Wheel Hub Inner Bearing Cup (10 1/2")	X				
205-422	Installer, Wheel Hub Oil Seal (10 1/2")	X				
205-423	Gauge, Drive Pinion Depth (10 1/2")	X				
205-425	Installer, LH Differential Carrier Oil Seal (Dana 50)	X				
205-426	Installer, RH Differential Carrier Oil Seal (Dana 60)	X				









2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-427	Installer, LH Differential Carrier Oil Seal (Dana 60)	X				
205-428	Bar, Oil Seal Spreader	X				
205-430	Collets, Differential Carrier Bearing	X				
205-431	Ring, Differential Carrier Bearing	X				
205-432	Plate, Differential Carrier Bearing	X				
205-433	Remover, Yoke	X				
205-435	Installer, Differential Yoke	X				
205-437	Installer, Drive Nut, Yoke	X				
205-440	Remover/Installer, Drive Pinion Oil Seal	X		X		
205-445	Installer, Wheel Hub Inner Oil Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-447	Gauge, Differential Clutch Preload	X				
205-460	Protector, Drive Pinion Thread	X		X		
205-461	Protector, Differential Oil Seal (pair)	X		X		
205-479	Installer, Drive Pinion Flange	X				
205-480	Installer, Drive Pinion Inner Bearing Cup	X		X		
205-486	Installer, Drive Pinion Bearing Cup	X				
205-487	Protector, Drive Pinion Thread	X				
205-488	Installer, Drive Pinion Bearing	X		X		
205-489	Remover, Drive Pinion Inner Bearing	X				
205-495	Installer, Transmission Output Shaft Flange	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-504	Installer, Halfshaft Pilot Bearing	X		X		
205-510	Cup, Axle Bushing Receiving	X				
205-527	Remover/Installer, Front Differential Housing Bushing	X		X		
205-529	Remover, Halfshaft	X		X		
205-796	Plug, ABS Sensor Vacuum Test	X				
205-813	Remover/Installer, Rear Drive Unit Bushing	X		X		
205-816	Protector, Differential Oil Seal (pair)	X		X		
205-826	Tool, Knuckle Seal Vacuum Test	X				
205-827	Tool, Vacuum Hub Test	X				
205-828	Stand, Hub Bearing	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-829	Stand, Hub Vacuum Test	X				
205-830	Installer, Wheel Knuckle Seal	X				
205-831	Installer, Wheel Knuckle Seal	X				
205-832	Remover, Halfshaft	X		X		
205-834	Installer, Drive Pinion Bearing	X				
205-852	Installer, Inner Pinion Bearing Cup	X		X		
205-882	Installer, PTU Linkshaft Seal Dust Shield	X		X		
205-883	Installer, PTU Linkshaft Seal	X		X		
205-907	Handle, 32" Driver	X		X		
205-935	Installer, Pinion Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-936	Pinion, Flange Installer	X				
205-937	Adapter, Pinion Aligning	X		X		
205-990	Installer, Axle Seal	X		X		
205-D002	Remover, Drive Pinion Bearing Cone		X		X	
205-D013	Plate, Step		X			
205-D014	Plate, Step		X			
205-D015	Plate, Step		X		X	
205-D016	Plate, Step		X		X	
205-D017	Plate, Step		X			
205-D018	Plate, Step		X			











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-D019	Plate, Step		X		X	
205-D020	Plate, Step		X			
205-D026	Puller, 2 Jaw		X			
205-D027	Puller, 2 or 3 Jaw		X			
205-D028	Adapter, Alignment		X			
205-D030	Disc, Gauge, 1.2692"		X			
205-D031	Adapter, Alignment, 1.740"		X			
205-D033	Tube, Gauge, 3.8135"		X			
205-D034	Tube, Gauge, 2.892"		X			
205-D035	Remover, 2 Jaw Puller		X			











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-D036	Puller, Drive Pinion/Differential Carrier		X			
205-D037	Disc, Gauge		X			
205-D038	Tube, Gauge		X			
205-D044	Installer, Differential Carrier Bearing		X		X	
205-D047	Set, Dummy Bearing		X			
205-D048	Set, Dummy Bearing		X			
205-D055	Handle		X		X	
205-D060	Tool, Limited Slip Preload		X			
205-D061	Plate, Step		X		X	
205-D062	Handle, Rotating		X			











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
205-D064	Puller, Bearing		X		X	
205-D067	Pliers, Boot Clamp		X		X	
205-D070	Remover, Front Wheel Hub		X		X	
205-D072	Puller, 2 Jaw		X		X	
205-DS004	Set, Shaft Protector		X		X	
205-DS011	Set, Step Plate Adapter		X		X	
205-DS023	Set, Push/Puller		X		X	
206-026	Adapter for 206-010	X		X		
206-033	Remover/Installer, Wheel Speed Sensor Ring	X				
206-034	Installer, Wheel Speed Sensor Ring	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
206-040	Installer, Parking Brake Bearing	X		X		
206-054	Installer, Wheel Speed Sensor Ring	X				
206-060	Installer, Wheel Speed Sensor Ring	X				
206-084	Installer, Wheel Speed Sensor Ring	X		X		
206-086	Gauge, Parking Brake Cable Adjustment	X				
206-D002	Gauge, Brake Adjustment		X		X	
206-D122	Adapter, Brake System		X			
211-001	Remover, Tie-Rod End	X				
211-003	Remover, Steering Arm	X		X		
211-006	Remover/Installer, Steering Gear Oil Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
211-007	Remover/Installer, Steering Gear Bearing	X				
211-008	Installer, Steering Gear Bushing	X				
211-009	Installer, Power Steering Pump Pulley	X				
211-012	Installer, Worm Bearing Locknut	X				
211-014	Remover, Steering Wheel	X				
211-016	Remover, Power Steering Pump Pulley	X		X		
211-023	C-Frame and Screw	X		X		
211-044	Installer, Sector Shaft Seal	X				
211-061	Remover, Roll Pin	X		X		
211-105	Remover, Tie-Rod End	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
211-185	Installer, Power Steering Pump Pulley	X		X		
211-265	Cap, Power Steering Evacuation	X		X		
211-327	Tool, Power Steering Vacuum Fill	X		X		
211-D009	Adapter, Power Steering Analyzer		X			
211-D019	Adapters, Power Steering		X			
211-D027	Set, Teflon Seal Installer		X		X	
211-S060	Set, Roll Pin	X				
303-004	Gauge, Valve Guide	X		X		
303-006A	Tester, Mini Spring	X		X		
303-009	Remover, Crankshaft Vibration Damper	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-016	Reamer, Cylinder Ridge	X		X		
303-050	Bracket, Engine Lifting	X		X		
303-088	Gauge, Oil Pressure	X		X		
303-093	Aligner, Front Cover	X				
303-096	Installer, Camshaft Front Oil Seal	X		X		
303-101	Remover, Crankshaft Vibration Damper	X				
303-102	Installer, Crankshaft Vibration Damper	X		X		
303-103	Holding Tool, Flywheel	X		X		
303-1039	Compressor, Valve Spring	X		X		
303-1040	Alignment Pins, Cylinder Head	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-1046	Locking Tool, Cam Phaser	X		X		
303-107	Remover, Crankshaft Front Oil Seal	X		X		
303-1097	Locking Tool, Variable Camshaft Timing Oil Control Unit	X				
303-1140	Bracket, Engine Lifting	X		X		
303-1175	Locking Tool, Timing Chain	X		X		
303-1245	Lift Eye, Engine	X		X		
303-1246	Bar, Engine Spreader	X		X		
303-1247	Remover/Installer, VCT Spark Plug Tube Seal	X		X		
303-1248	Tools, Camshaft Holding	X		X		
303-1249	Compressor, Valve Spring	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-1250	Installer, Rear Main Seal	X		X		
303-1251	Installer, Front Seal	X		X		
303-1252	Remover/Installer, Stretchy Belt	X		X		
303-1261	Cups, Injector	X				
303-1295	Fixture, Oil Pan	X		X		
303-1317	Locking Tool, Fuel Injection Pump Sprocket	X				
303-1416	Tool, Crank Damper Holding	X		X		
303-1417	Tool, Crank Sensor Alignment	X		X		
303-1418	Compressor, Valve Spring	X		X		
303-1419	Remover, 3.5L / 3.7L Stretchy Belt	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-1454	Bar, Engine Spreader	X		X		
303-1502	Eye, Lifting	X				
303-1507	Brackets, Support	X				
303-1508	Installer, Front Crank Seal	X				
303-1509	Installer, Front Crank Seal	X				
303-1510	Remover, Front Crank Seal	X				
303-1511	Tester, EGR Cooler Pressure	X				
303-1513	Remover, Rear Crank Seal	X				
303-1514	Installer, Rear Crank Seal	X				
303-1515	Adapter, Compression Test	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-1516	Compressor, Valve Spring	X				
303-1517	Adapter, Camshaft Remover/Installer	X				
303-1518	Bracket, Engine Removal	X				
303-1521	Alignment Tool, Crankshaft Position Sensor	X		X		
303-1525	Flusher, Engine	X				
303-1528	Remover/Installer, Water Tube Seal	X		X		
303-1529	Lift Eye, Engine	X		X		
303-1530	Tool, Chain Tensioner Hold Down	X		X		
303-1531	Installer, Front Crank Seal and Damper	X		X		
303-1532	Installer, Camshaft Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-1550	Alignment Tool, Crankshaft Vibration Damper	X				
303-1552	Alignment Tool, Camshaft	X				
303-1556	Locking Tool, Timing Belt	X				
303-1561	Holding Wrench, Pulley	X				
303-1562	Tool, Crankshaft Timing	X				
303-1565	Alignment Tool, Camshaft	X		X		
303-1566	Lift Eye, Right Front	X				
303-1567	Sizer, Teflon Seal	X		X		
303-1587	Timing Tool, Crankshaft	X				
303-1602	Locking Tool, Crankshaft	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-1603	Installer, Front Cover Seal	X				
303-1604	Timing Peg, Crankshaft TDC	X				
303-1605	Alignment Tool, Camshaft	X				
303-1606	Locking Tool, Variable Camshaft Timing	X				
303-1611-01	Adapter for 303-1611	X				
303-1611-02	Adapter for 303-1611, Torque Multiplier	X				
303-1633	Remover, Roller Rocker Follower	X		X		
303-1634	Fixture, Engine Lift Eyes	X		X		
303-1638	Socket, Block Heater	X				
303-175	Installer, Crankshaft Vibration Damper	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-178	Installer, Crankshaft Rear Main Oil Seal	X		X		
303-214	Wrench, Fan Clutch Nut	X				
303-239	Holding Wrench, Fan Pulley	X				
303-240	Wrench, Fan Clutch Nut	X				
303-249	Remover, Crankshaft Timing Pulley	X				
303-249-01	Adapter, Crankshaft Timing Pulley	X				
303-290-01	Adapter for 303-290A	X				
303-290-05A	Adapter for 303-290A	X		X		
303-290A-03A	Adapter for 303-290A (Support Leg)	X				
303-290A-12	Adapter For 303-290A (Support Hook)	X				










2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-290B	Support Bar, Engine	X				
303-290B-18	Adapter for 303-290B	X				
303-290B-19	Adapter for 303-290B	X		X		
303-293	Remover, Crankshaft Seal	X				
303-300	Set, Valve Spring Compressor	X		X		
303-328	Replacer, Rear Seal	X		X		
303-335	Installer, Front Cover Oil Seal	X		X		
303-350	Compressor, Valve Spring	X		X		
303-370	Installer, Valve Stem Oil Seal	X				
303-376B	Alignment Plate, Camshaft	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-380	Aligner, Camshaft	X				
303-382	Compressor Spacer, Valve Spring	X		X		
303-383	Installer, Valve Stem Oil Seal	X		X		
303-384	Installer Bolts, Crankshaft Rear Main Oil Seal	X		X		
303-393-02	Adapter For 303-393A	X				
303-393A	Locking Tool, Flywheel	X				
303-409	Remover, Crankshaft Seal	X		X		
303-413	Aligner, Camshaft Pulley	X				
303-420	Installer, Crankshaft Front Oil Seal	X		X		
303-442	Installer, Connecting Rod	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-446	Holding Tool, Camshaft	X				
303-448	Holding Tool, Crankshaft	X		X		
303-452	Compressor, Valve Spring	X				
303-456	Plate, Water Pump Pulley	X		X		
303-457	Protector, Water Pump Shaft	X		X		
303-458	Installer, Camshaft Pulley	X		X		
303-459	Spacer, Water Pump Pulley	X		X		
303-463	Protector, Camshaft Oil Seal	X		X		
303-464	Installer, Camshaft Oil Seal	X		X		
303-465	Tool, Camshaft Align Timing	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-468	Remover, Valve Stem Oil Seal	X		X		
303-470	Installer, Valve Stem Oil Seal	X		X		
303-472	Compressor, Valve Spring	X		X		
303-473	Compressor, Valve Spring	X		X		
303-476	Socket, Exhaust Gas Oxygen Sensor	X		X		
303-478	Holding Wrench, Fan Clutch Pulley	X				
303-507	Timing Peg, Crankshaft TDC	X		X		
303-514	Remover, Crankshaft Rear Oil Slinger	X		X		
303-516	Installer, Crankshaft Rear Oil Seal	X		X		
303-517	Installer, Crankshaft Rear Oil Slinger	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-518	Installer, Crankshaft Rear Oil Seal	X		X		
303-519	Remover, Crankshaft Rear Oil Seal	X		X		
303-527	Adapter for 303-579	X				
303-528	Screws, Crankshaft Rear Oil Seal	X				
303-557	Aligner, Camshaft Position	X		X		
303-564	Holding Tool, Camshaft Sprocket	X				
303-565	Socket, Camshaft Sprocket Nut	X				
303-567	Compressor, Valve Spring	X		X		
303-571	Tensioner, Timing Chain	X				
303-572	Remover/Installer, Cylinder Head	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-572	Remover/Installer, Cylinder Head	X		X		
303-575	Extension, Torque Wrench	X				
303-576	Adapter for 303-577	X				
303-577	Holding Tool, Camshaft	X				
303-578	Adapter for 303-564	X				
303-578	Adapter for 303-564	X				
303-579	Installer, Crankshaft Rear Seal	X				
303-581	Compressor, Valve Spring	X		X		
303-634	Socket, Rear Jack Shaft	X				
303-635	Installer, Crankshaft Front Oil Seal	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-639	Support Bracket, Engine	X		X		
303-674	Holding Tool, Crankshaft	X				
303-679A	Remover/Installer, Engine Front Cover Inspection Plate	X				
303-682	Aligner, Engine Front Cover	X				
303-705	Aligner, Oil Pump	X				
303-748	Locking Tool, Crankshaft	X				
303-773	Remover, Crankshaft Vibration Damper	X				
303-D011	Pin, Actuator, (Dia 3/16")		X		X	
303-D012	Pin, Actuator		X		X	
303-D019	Collet, 3/4" To 7/8"		X		X	











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-D020	Collet, 7/8" to 1"		X		X	
303-D021	Collet, 1" to 1 1/4"		X			
303-D022	Collet, 1 1/4" to 1 1/2"		X		X	
303-D026	Micrometer, Depth		X			
303-D027	Set, Feeler Gauge		X		X	
303-D030	Tool, Lifting Eyes Mounting		X			
303-D032	Compressor, Piston Ring		X		X	
303-D033	Scraper, Piston Ring Groove		X		X	
303-D055	Wrench, Strap		X		X	
303-D075	Micrometer, Depth		X		X	











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-D087	Lifting Bracket, Engine		X		X	
303-D088	Lifting Bracket, Engine		X		X	
303-D089	Bar, Spreader		X		X	
303-D099	Lifting Bracket, Engine		X			
303-D104	Gun, Oil Suction		X		X	
303-D114	Holding Rack, Fuel Injector		X			
303-D121	Puller, General Purpose		X		X	
303-DS086	Lifting Bracket Set, Engine		X		X	
303-F047	Lifting Bracket, Engine	X		X		
303-F070	Support Bar, Engine	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
303-F072	Support Bar, Engine	X		X		
303-F694	Adapter, Modular Engine	X				
307-001	Remover, Bushing	X				
307-002	Installer, Shift Shaft Fluid Seal	X				
307-003	Holding Fixture, Transmission	X		X		
307-003	Holding Fixture, Transmission	X		X		
307-004	Gauge, Transmission Fluid Pressure	X		X		
307-005	Slide Hammer	X		X		
307-014	Installer, Front Pump Fluid Seal	X		X		
307-015	Compressor, Clutch Spring	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-016	Remover, Front Pump Bushing	X				
307-020	Protector, Piston Seal	X		X		
307-038	Installer, Transmission Extension Housing Fluid Seal	X				
307-048	Remover, Transmission Fluid Seal	X		X		
307-050	Installer, Shift Shaft Seal	X		X		
307-051	Protector, Piston Seal	X				
307-052	Protector, Piston Seal	X				
307-065	Installer, Transmission Extension Housing Bushing	X				
307-072	Gauge, Shim Selection	X		X		
307-073	Installer, Servo Piston	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-077	Remover/Installer, Transmission Extension Housing	X		X		
307-078	Protector, Piston Seal	X		X		
307-080	Protector, Piston Seal	X		X		
307-091	Handle, Torque Converter	X		X		
307-096	Compressor, Clutch Spring	X		X		
307-126	Test Plate Screw Set, Transmission	X		X		
307-162	Gauge, Servo Rod	X				
307-163	Remover, Stator Case Bearing	X		X		
307-181	Installer, Transaxle Bearing Cone	X		X		
307-209	Compressor, Spring Washer	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-221	Remover, Transmission Fluid Pump	X		X		
307-222	Aligner, Transmission Fluid Pump	X				
307-246	Air Test Plate, Transmission	X		X		
307-251	Remover/Installer, Servo Piston	X		X		
307-256	Installer, Differential Fluid Seal	X				
307-262	Holding Fixture, Transmission	X				
307-263	Gauge, Shim Selection	X				
307-300	Gauge Bar, Shim Selection	X		X		
307-309	Remover, Torque Converter Seal	X		X		
307-318	Remover, Stator Bearing	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-331	Aligner, Torque Converter	X				
307-333	Aligner, Valve Body	X				
307-334	Aligner, Valve Body	X				
307-335	Sizer, Piston Seal	X				
307-337	Gauge, TSS	X				
307-338	Sizer, Piston Seal	X				
307-340	Compressor, Servo Cover	X				
307-343	Pliers, Retaining Ring	X		X		
307-346	Retainer, Torque Converter	X		X		
307-347	Remover, Servo	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-349	Installer, Torque Converter Fluid Seal	X				
307-351	Alignment Gauge, Transmission Range (TR) Sensor	X		X		
307-353	Sizer, Piston Seal	X				
307-375	Installer, Needle Bearing	X				
307-376	Installer, Fluid Filler Tube	X				
307-382	Remover, Output Shaft Bushing	X				
307-384	Fixture Handle, Coast Clutch	X				
307-385	Fixture Body, Coast Clutch	X				
307-387	Protector, Clutch Piston Seal	X				
307-391	Sleeve, One-Way Clutch	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-392	Installer, One-Way Clutch	X				
307-396	Installer, Reverse Drum/One-Way Clutch	X				
307-397	Remover, Transmission Fluid Pump	X		X		
307-399	Alignment Pins, Transmission Fluid Pump	X		X		
307-400	Bar, Gauge	X				
307-410	Mounting Bracket, Transmission	X				
307-412	Plate, Transmission Air Test	X				
307-413	Holding Tool, Final Drive Input Gear	X				
307-414	Socket, Final Drive Input Nut	X				
307-415	Alignment Gauge, Transmission Range (TR) Sensor	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-416	Adjustment Bolt, Transmission Band	X				
307-417	Gauge, Differential/Transfer Gear Bearing Shim	X				
307-418	Installer, Transfer Gear Bearing Cup	X				
307-420	Holding Fixture, Final Drive	X				
307-421	Leak Tester, Torque Converter	X		X		
307-422	Protector, Transmission Direct Clutch Outer Fluid Seal	X		X		
307-424	Protector, Transmission Reverse Clutch Outer Fluid Seal	X		X		
307-425	Protector, Transmission Reverse Clutch Inner Fluid Seal	X		X		
307-428	Installer, RH Halfshaft Seal	X		X		
307-429	Remover, RH Halfshaft Fluid Seal	X		X		






2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-431	Alignment Gauge, Transmission Fluid Pump	X				
307-432	Alignment Gauge, Transmission Fluid Pump	X				
307-436	Installer, Transmission Forward Clutch Assembly	X				
307-436-02	Adapter for 307-436	X				
307-441	Disconnect Tool, Transmission Cooler Line	X				
307-451	Installer Tools, Transmission Fluid Pump Seal	X				
307-453	Installer, Transmission Extension Housing Seal	X				
307-454	Remover, Transmission Extension Housing Seal	X				
307-455	Aligner, Clutch Spring Compressor	X				
307-456	Aligner, Valve Body	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-457	Air Test Plate, Transmission	X				
307-458	Socket, Output Shaft Locknut	X				
307-459	Disconnect Tool, Transmission Cooler Line	X				
307-460	Remover, Output Shaft Seal/Housing	X				
307-461	Installer, Output Shaft Seal/Housing	X				
307-462	Installer, Output Shaft Seal	X				
307-466	Alignment Pins, Transmission Fluid Pump	X				
307-516	Installer, Teflon Seal	X		X		
307-523	Remover, Output Flange	X		X		
307-525	Compressor, Clutch Spring	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-534	End Play Gauge, Transmission	X		X		
307-541	Installer, Transfer Gear Bearing	X		X		
307-548	Installer, Fluid Pump Seal	X		X		
307-549	Installer, Shift Shaft Fluid Seal	X		X		
307-552	Compressor, Clutch Spring	X		X		
307-553	Remover, Transmission Fluid Pump	X		X		
307-554	Gauge, D-Clutch Measurement	X		X		
307-555	End Play Gauge, Clutch	X		X		
307-556	Installer, Fluid Pump Seal	X		X		
307-557	Installer, Ball Bearing	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-559	Installer, Shifter Fluid Seal	X		X		
307-562	Remover, Needle Bearing	X		X		
307-566	Retainer, Torque Converter	X		X		
307-567	Installer, Axle Seal	X		X		
307-568	Installer, Axle Seal	X		X		
307-569	Tool, TOC Line Disconnect, 1/2"	X		X		
307-570	Tube, Transmission Fill	X		X		
307-572	Installer, Axle Seal	X				
307-574	Compressor, Forward Clutch Spring	X		X		
307-575	Installer, Converter Seal	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-576	Installer, Bearing Cup	X		X		
307-577	Remover, Transfer Gear Bearing Race	X		X		
307-579	Installer, Support Solid Seal, Single Seal	X		X		
307-580	Fixture, Holding	X		X		
307-581	Installer, Manual Lever Seal	X		X		
307-582A	Installer, Cover Axle Seal	X		X		
307-583	Installer, Oil Dam Seal	X		X		
307-584	Compressor, 2-6 Spring	X		X		
307-585	Installer, Support Seal	X		X		
307-586	Remover, Differential Bearing Cup	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-587	Installer and Guide, Differential Bearing	X		X		
307-588	Set, Reverse Clutch Piston and Retaining Ring	X		X		
307-589	Set, Overdrive Clutch and Balance Piston Service	X		X		
307-591	Shim Gauge, Differential/Transfer Gear Bearing	X		X		
307-592	Installer, Manual Lever Retaining Pin	X		X		
307-593	Installer, Axle Seal	X		X		
307-625	Fixture, Bench Mounting	X		X		
307-626	Installer, Differential Seal	X		X		
307-627	Installer, Converter Seal	X		X		
307-628	Protector, Low Reverse Piston Seal	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-629	Protector, Low Reverse / 1-2-3-4 Piston Seal	X		X		
307-630	Tool, Center Support Piston Spring	X		X		
307-632	Protector, 2-6 Piston Seal	X		X		
307-633	Compressor, 2-6 Piston Return Spring	X		X		
307-635	Protector, Turbine Shaft Seal	X		X		
307-636	Body, Alignment Pins-Valve	X		X		
307-637	Installer, 6R80 Rear Seal 4X4	X		X		
307-638	Installer, 6R80 Rear Seal 4X2	X		X		
307-639	Remover/Installer, 6R80 Rear Bearing	X		X		
307-647	Installer, Output Shaft Bearing	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-648	Remover/Installer, Rear Bearing	X				
307-649	Socket, Output Shaft Nut	X				
307-650	Installer, Output Shaft Seal	X				
307-651	Bracket, Pump Remover/Installer	X				
307-652	Plate, C-Clutch Air	X				
307-653	Sizer, Input Shaft Teflon Seal	X				
307-654	Pliers, Snap Ring	X				
307-655	Installer, Center Support Bearing	X				
307-657	Installer, Pump Seal - Non-PTO	X				
307-658	Compressor, C Clutch Return Spring	X				

2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-659	Installer/Sizer, Pump Seal PTO	X				
307-660	Installer, Front Pump Seal	X				
307-661	Gauge, End Play	X				
307-662	Gauge, Clutch Pack Endplay	X				
307-664	Installer, Case Bushing	X		X		
307-665	Installer, Differential Seals, LH and RH (Two sided Tool)	X		X		
307-670	Remover/Installer, Shift Lever Seal	X				
307-671	Installer, Axle Seal	X				
307-672	Installer, Input Guide and Seal	X		X		
307-673	Remover, Outer Input Shaft Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-674	Installer, Outer Input Seal	X				
307-675	Fixture, Clutch Remover/Installer	X				
307-676	Tool, Clutch 1 and 2 Reset	X				
307-677	Socket, Actuator Reset	X				
307-678	Remover, Bearing cone	X				
307-679	Installer, Countershaft Needle Bearing	X				
307-680	Table, Assembly (DPS6)	X				
307-681	Tool, Differential Bearing Preload	X				
307-689	Installer, Bearing Cup	X		X		
307-691	Tester, Torque Converter Leak	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-692	Tool, Transfer Gear Preload	X		X		
307-693	Installer, Transfer Gear Bearing Cup	X		X		
307-694	Installer, Manual Lever Seal	X		X		
307-695	Tool, Quick Disconnect 1/2 Inches	X				
307-696	Remover, TRS Retaining Pin	X		X		
307-708	Installer, Lube Tube	X				
307-713	Installer, Roller Bearing	X		X		
307-714	Installer, Needle Bearing	X				
307-715	Installer, Output Seal (4X2)	X		X		
307-716	Installer, Teflon Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
307-717	Remover, Kostal Sleeve	X		X		
307-718	Installer, Axle Seal	X		X		
307-722	Protector, Clutch Bearing	X				
307-723	Installer, Turbine Seal	X		X		
307-724	Protector, Center Support Seal	X				
307-725	Fixture, Bench Mounting	X				
307-D004	Banding Tool, Transmission Pump		X			
307-S039	Alignment Set, Fluid Pump	X				
307-S383	Loading Fixture, Clutch	X				
308-001	Remover, Pilot Bearing	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-002	Installer, Transmission Extension Housing Oil Seal	X		X		
308-006	Aligner, Clutch Disc	X		X		
308-017	Installer, Bearing Cup	X				
308-020	Aligner, Clutch Disc	X				
308-021	Gauge, Clutch Housing	X		X		
308-024	Remover/Installer, Bearing Tube	X				
308-025	Remover/Installer, Bearing Tube	X				
308-031	Installer, Bearing Shaft Collar	X				
308-039	Installer, Halfshaft Seal	X				
308-045	Installer, Transmission Extension Housing Bushing/Seal	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-047	Remover, Bearing Cup	X		X		
308-052	Remover/Installer, Bearing Tube	X				
308-057	Installer, Clutch Housing Oil Seal	X		X		
308-058	Remover, Mainshaft Bearing	X				
308-059	Remover, Mainshaft Bearing	X				
308-060	Installer, Mainshaft Bearing	X		X		
308-061	Installer, Bearing	X				
308-062	Installer, Input Shaft Bearing	X				
308-070	Remover, Transmission Extension Housing Bushing	X		X		
308-082	Remover, Input Shaft Fifth Gear	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-085	Installer, Input Shaft Bearing	X		X		
308-089	Installer, Needle Bearing	X				
308-092	Removal Screw, Bearing Tube	X				
308-097	Installer, Oil Seal	X				
308-098	Remover/Installer, Bearing Tube	X				
308-105	Installer, Pilot Bearing	X		X		
308-112	Installer, Output Drive Flange Seal	X				
308-119	Installer, Halfshaft Seal	X		X		
308-125	Remover, Transfer Case Bearing	X		X		
308-130	Installer, Shift Rail Needle Bearing	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-153	Installer, Differential Bearing Cup	X				
308-155	Installer, Differential Bearing Cup	X		X		
308-160	Turning Torque Socket, Transmission	X				
308-162	Installer, Differential Bearing Cup	X		X		
308-163	Installer, Differential Bearing Cup	X				
308-164	Set, Shim Selection	X		X		
308-165	Rotator, Differential	X		X		
308-168	Socket, Transmission Shaft Locknut	X				
308-169	Installer, Shaft Bearing Cone	X		X		
308-171	Remover, Front Cover	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-174	Spacer, Gear	X				
308-182	Disconnect Tool, Hydraulic Line	X				
308-186	Installer, Input Shaft Oil Seal	X		X		
308-201	Remover, Input Shaft Bearing	X				
308-202	Installer, Input Shaft Bearing	X				
308-216	Fixture, Dial Indicator Gauge Holding	X				
308-220	Installer, Input Shaft Oil Seal	X				
308-221	Installer, Shaft Bearing Cup	X		X		
308-222	Installer, Differential Seal	X				
308-224	Socket, Input Shaft	X				

2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-225	Installer, Differential Bearing Cup	X				
308-249	Installer, Input Shaft Oil Seal	X		X		
308-250	Installer, Output Shaft Oil Seal	X				
308-251	Protector, Shaft Oil Seal	X				
308-256	Remover, Halfshaft	X				
308-375	Remover, Input Shaft Seal	X		X		
308-391	Installer, Input Shaft Bearing Cup	X		X		
308-399	Installer, Output Shaft Oil Slinger	X				
308-400	Installer, Output Shaft Oil Slinger	X				
308-401	Installer, Output Shaft Rear Bearing	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-402	Installer, Transfer Case Needle Bearing	X				
308-403	Installer, Output Shaft Oil Seal	X				
308-404	Sleeve, Output Shaft Rear Snap Ring	X				
308-405	Sleeve, Output Shaft Front Snap Ring	X				
308-406	Sleeve, Input Shaft Snap Ring	X				
308-410	Installer, Output Shaft Front Bearing	X		X		
308-411	Installer, Output Shaft Rear Bearing	X				
308-412	Installer, Input Shaft Bearing	X				
308-416	Remover/Installer, Thrust Washer Bearing Cup	X				
308-427	Installer, PTO Shaft Inner/Outer Oil Seal	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-428	Remover, PTO Driven Gear Oil Seal	X		X		
308-429	Installer, PTO Driven Gear Oil Seal	X				
308-430	Installer, PTO Drive Gear Outer Oil Seal	X		X		
308-431	Installer, Halfshaft Oil Seal	X		X		
308-432	Installer, PTO Dust Flange	X				
308-579	Installer, Output Shaft Seal	X				
308-580	Installer, Second Gear Bushing	X				
308-581	Installer, Sixth Gear Bushing	X				
308-582	Installer, Input Shaft Bearing	X				
308-584	Installer, Vent Tube	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-599	Aligner, Clutch	X				
308-777	Remover/Installer, PTU Input Shaft Seal	X		X		
308-800	Installer, Input Seal	X				
308-801	Guide, Input Shaft Snap Ring	X				
308-806	Installer, Front Seal	X				
308-807	Holding Tool, Rear Flange	X				
308-875	Installer, Inboard Cover Seal	X		X		
308-876	Installer, Outboard Cover Seal	X		X		
308-877	Installer, Pinion Output Seal	X		X		
308-878	Installer, Input Seal	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
308-D002	Aligner, Clutch		X			
310-040	Tool, Fuel Pipe Disconnect, 5/16"	X		X		
310-069	Wrench, Fuel Tank Sender Unit	X				
310-102	Hose, Fuel Draining	X		X		
310-123	Locking Ring, Fuel Tank	X		X		
310-159	Adapter, Fuel Line	X				
310-180	Adapter, Fuel Pressure Test	X		X		
310-205	Brush, Fuel Injector	X		X		
310-206	Remover, Fuel Injector	X		X		
310-207	Installer, Fuel Injector Seal Assembly	X		X		











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
310-230	Remover, Fuel Injector	X				
310-230-01	Adapter, Fuel Line Injector Remover	X				
310-250	Disconnect Tool, Fuel Line	X		X		
310-D004	Tool, Spring Lock Coupling Disconnect, 3/8", Yellow		X		X	
310-D005	Tool, Spring Lock Coupling Disconnect, 1/2", Green		X			
310-D006	Socket, Fuel Tank Sender Unit		X			
310-D009	Kit, Fuel Pressure Test		X		X	
310-D251	Adapter, Fuel Pressure T, 5/16"		X		X	
310-D252	Adapter, Fuel Pressure T, 3/8"		X			
310-F013	Hose, Fuel Tank Drain	X				











2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
310-S039	Disconnect Tool, Spring Lock Coupling	X		X		
412-001	Remover, Compressor Pulley	X		X		
412-035	Remover, Damaged Evaporator Core Orifice	X		X		
412-039	Remover, Refrigerant Coupling Spring	X		X		
412-042	Remover, Heater Hose Inlet Tube	X		X		
412-058	Installer, A/C Compressor Shaft Oil Seal	X				
412-059	Remover, A/C Compressor Shaft Oil Seal	X				
412-063	Remover, A/C Compressor Snap Ring	X				
412-065	Installer, A/C Compressor Coil	X		X		
412-067	Remover, A/C Compressor Field Coil	X		X		






2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
412-078	Installer, A/C Compressor Field Coil	X		X		
412-093	Connector, Refrigerant Pressure Line	X				
412-094	Protector, A/C Compressor Shaft Oil Seal	X				
412-098	Holding Fixture, Compressor Clutch	X				
412-134	Holding Tool, Compressor Clutch	X		X		
412-136	Installer, A/C Clutch	X				
412-137	Protector, A/C Shaft	X				
412-145	Connector, Refrigerant Flushing Equipment	X				
412-150	Holding Tool, A/C Clutch	X				
415-001	Remover, Audio Unit	X				

2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
415-D009	Remover, Audio Unit		X			
416-D002	Kit, Vacuum Pump		X		X	
418-133	Simulator, Side Air Bag	X		X		
418-F088	Tool, Restraint System Diagnostic Service	X		X		
418-F395	Tool, Restraint System Diagnostic Service	X		X		
501-010	Torx Bit, Safety Belt Bolt	X				
501-025	Installer, Rear View Mirror	X		X		
501-039	Remover, Power Point Socket	X		X		
501-117	Tool, Fire Suppression Diagnostic	X				
501-190	Remover, Auto Dimming Rear View Mirror	X		X		

2016 Ford and Lincoln New Dealer Kits' Contents

Tool Number	Tool Name	Used to service Ford and Lincoln vehicles		Used to service only Lincoln vehicles		Tool Illustration
		Essential tools only 014-NDK-FL-2016	Desired tools only 014-DNDK-FL-2016	Essential tools only 014-NDK-L-2016	Desired tools only 014-DNDK-L-2016	
501-191	Installer, Rear View Mirror	X		X		
501-194	Remover, Power Point	X		X		
501-403	Tool, Pretensioner Quick Connect	X		X		
501-411	Mats, 360 Camera Calibration	X		X		
501-D118A	Remover, Mirror		X		X	
502-002	Alignment Pins, Subframe	X		X		